


USE AND CARE GUIDE DH-01



Note: The specifications and/or components of this appliance are subject to change without prior notice

Table of Contents

Table of Contents	2
Safety Information	3
Warranty	5
Pre-Operation	6
Package Contents	6
Specifications	6
Recommended Locations	7
Proper Placement	7
Operation	8
Using the Dehumidifier	8
Using the Water Tank	8
Maintenance	9
Vacation Time Storage	9
Moving Your Dehumidifier	9
Care & Cleaning	10
Cleaning the Panels	10
Cleaning the Water Tank	10
Troubleshooting	11

Safety Information



DANGER: Risk of electrocution. To reduce the risk of electrocution, please consider the following safety precautions.

- Do not use the dehumidifier in the bathroom.
- Do not place the dehumidifier where water could drip onto the unit or the adaptor.



WARNING: Important Electrical Safety Precautions

- Verify that your household electrical rating is adequate for the model you have chosen. This information can be found on the rating label, which is located on the AC adaptor.
- Connect the dehumidifier into a properly grounded wall outlet. If the wall outlet you intend to use is not adequately grounded or protected by a time delay fuse or circuit breaker, have a qualified electrician install the proper outlet.
- Verify that the dehumidifier is properly grounded. The dehumidifier has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, the plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way. If the plug fits loosely into the electrical outlet or if the electrical outlet feels warm, do not use the particular outlet.
- Verify that the wall outlet is accessible after the unit is installed.

Safety Information (Continued)



WARNING: To reduce the risk of fire, electrical shock, and/or injury to persons, basic safety precautions should always be followed when using electrical appliances.

Do Not:

- Do not modify the power cord or share the outlet with other appliances.
- Do not touch or operate the unit when barefoot or with wet or damp hands.
- Do not operate the buttons on the control panel with anything other than your fingers.
- Do not remove any fixed panels. Never use the dehumidifier if it is not working properly or if it has been dropped or damaged.
- Do not use the plug to start and stop the unit. Always use the power switch on the control panel.
- Do not restrict or obstruct the airflow inlet or outlet grills.
- Do not use abrasive cleaning products or spray liquids to clean the dehumidifier.
- Do not operate the dehumidifier in the presence of flammable substances or vapors such as alcohol, insecticides, gasoline, etc.
- Do not place the power cord near flammable gas or combustibles such as gasoline, benzene, thinner, etc.
- Do not use the dehumidifier outdoors for commercial or industrial applications. The dehumidifier is for household use only.
- Do not allow children or incapacitated persons to operate the dehumidifier.
- Do not use the dehumidifier for anything other than its intended purpose and as described in the instruction manual.
- Do not disassemble or modify the dehumidifier. It may cause unit failure, electric shock, fire, and/or injury to persons.
- Do not direct airflow towards room occupants. This may impact the health of occupants.
- Do not direct airflow at a pet or plant. This may injure the pet or plant.
- Do not drink water drained from the dehumidifier. It contains contaminants that can cause illness.

Do:

- Use caution when unpacking and installing the unit. Sharp edges may cause injury.
- Properly connect the power plug. Otherwise, it may cause fire due to excess heat generation.
- Use the dehumidifier in such a way that it is protected from moisture (e.g. condensation, water, etc.). Do not place or store the dehumidifier where it can fall into water or any other liquid. If this occurs, immediately unplug the unit and call Customer Service.
- If the dehumidifier is knocked over during use, immediately turn the unit off and unplug it from the main power supply.
- Always transport the dehumidifier in a vertical position and place the unit on a stable, level surface during use.
- Turn the dehumidifier off when not in use.
- If the power supply cord is damaged, always contact a qualified service technician for repairs.
- Place the dehumidifier away from any object, and ensure that the front, sides, and rear of the unit are clear of any debris.
- Ventilate the room before operating the dehumidifier, especially if there is a gas leakage from another appliance.
- Ventilate the room when operating the dehumidifier together with a stove or similar products; an oxygen shortage may occur.
- Keep firearms away from the dehumidifier, as it may cause fire.

Warranty

Limited Warranty

The supplier warrants each new 4-Pint Dehumidifier to be free from defects in material and workmanship, and agrees to remedy any such defect or to furnish a new part(s), at the company's option, for any part(s) of the unit that has failed during the warranty period. Parts and labor expenses are covered on this unit for a period of one year from the date of purchase. A copy of the dated sales receipt or invoice is required to receive warranty service by an authorized service agent.

The warranty does not cover the following:

- Damages due to shipping damage or improper installation
- Damages due to misuse or abuse
- Content losses due to failure of the unit
- Inside components such as light bulb, etc
- Repairs performed by unauthorized service agents
- Service calls that do not involve defects in material and workmanship such as instructions on proper use of the product or improper installation
- Replacement or resetting of house fuses or circuit breakers
- Failure of this product if used for other than for its intended purpose
- Disposal costs for any failed unit not returned to our factory
- Any delivery costs incurred as the result of a unit that fails to perform as specified
- Expenses for travel and transportation for product service if your appliance is located in a remote area where service by an authorized service technician is not available
- The removal and reinstallation of your appliance if it is installed in an inaccessible location or is not installed in accordance with published installation instructions


Limitations of Remedies and Exclusions

Product repair in accordance with the terms herein, is your sole and exclusive remedy under this limited warranty. Any and all implied warranties including merchantability and fitness for a particular purpose are hereby limited to one year or the shortest period allowed by law. The manufacturer is not liable for incidental or consequential damages and no representative or person is authorized to assume for us any other liability in connection with the sale of this product. Under no circumstances is the consumer permitted to return this unit to the factory without prior written consent of the manufacturer.

Product No	Parts & Labor	Type of Service
DH-01	One-Year	Carry-In

Pre-Operation

PACKAGE CONTENTS



Part	Description
A	LED Indicator Lights
B	Front Panel
C	Water Level Indicator
D	AC Adapter (Power Cord)

Part	Description
E	Polarized Plug
F	Power Switch (On/Off)
G	Back Panel
H	Water Tank

SPECIFICATIONS

Product No	DH-01
Voltage	100-240V ~ 50-60Hz
Rated Power	60W ± 10%
Operation Temperature	86°F
Operation RH	RH80%
Unit Dimensions	205*130*340mm
Unit Weight	1.98KG
Water Tank Capacity	1.5 Liter
Daily Dehumidification Rate	4-Pint under condition of 86°F and RH80%


Pre-Operation (Continued)

1 RECOMMENDED LOCATIONS



WARNING: To reduce the risk of fire, electrical shock, and/or injury to persons, basic safety precautions should always be followed when using electrical appliances.

- Place the dehumidifier away from any object, and ensure that the front, sides, and rear of the unit are clear of any debris.
- Use the dehumidifier to prevent moisture damage anywhere books or valuables are stored.
- Use the dehumidifier in the basement to help prevent moisture damage.
- Operate the dehumidifier in an enclosed area to increase its effectiveness.
- Close all doors, windows and other outside openings to the room, except when operating the dehumidifier together with a stove or similar products; as an oxygen shortage may occur.




2 PROPER PLACEMENT

- Select a suitable location, making sure you have easy access to the electrical outlet; do not place the dehumidifier outdoors.
- Place the dehumidifier on a smooth, level surface strong enough to support the unit with a full tank of water.



NOTE: Do not connect the dehumidifier to an outlet with multiple sockets shared with other electrical appliances.



Operation

USING THE DEHUMIDIFIER

1. To start operation, press the power button to the ON position ("o"). A green LED light on the front panel will illuminate.
2. To stop operation, press the power button to the OFF position ("o").
3. When first using the dehumidifier, operate the unit continuously for 24 hours.
4. If the unit has been switched off and needs to be switched on again quickly, allow approximately three minutes before restarting.




NOTE: Do not restrict or obstruct the airflow from the air outlet.

USING THE WATER TANK


1 WATER TANK FULL INDICATOR

- When the water tank is full, the dehumidifier will automatically stop operation. A red LED light (A) below the will flash.



2 WATER TANK REMOVAL


- Slowly pull out the water tank (H). Grip the left and right handles securely, and carefully pull the water tank out straight to avoid water spillage.



NOTE: After removing the water tank, do not touch any internal parts of the unit; doing so may cause damage.


3 WATER DISPOSAL

- Pull out the rubber plug (1) and dispose of the water.



4 REINSTALLATION

- Secure the rubber stopper into the water tank (H), and reinstall the tank into its correct position.



NOTE: The dehumidifier will not operate unless the water tank is inserted securely.

Maintenance

VACATION TIME STORAGE

- Press the power button to the OFF position ("o") and unplug the power supply cord from the wall outlet.
- Clean the unit and the water tank.
- Leave the water tank open to avoid possible odor or mold formation.
- Loosely wrap the power supply cord and bundle it with the band or place the excess cord onto the power supply cord hook (depending on model).
- Store the dehumidifier upright in a dry and well-ventilated place.

MOVING YOUR DEHUMIDIFIER

- Press the power button to the OFF position ("o") and unplug the power supply cord from the wall outlet.
- Remove the water tank and empty the collected water before moving the unit.
- Use the molded handle at the top of the back panel to transport the dehumidifier in a vertical position.

Care and Cleaning

CLEANING THE PANELS



CAUTION: Press power button to the OFF position ("o") and unplug the power supply cord from the wall outlet before cleaning the unit.

- Always clean the panels of the dehumidifier with a soft damp cloth. Do not use abrasive cleaners or spray liquids on the surface of the panels.
- Do not clean the dehumidifier or the unit parts with flammable liquids. The fumes can create a fire hazard.

CLEANING THE WATER TANK



WARNING: Do not clean the water tank using a dishwasher.

- Every few weeks, clean the water tank using nonabrasive cleaners to prevent the growth of mold, mildew, and bacteria.
- Partially fill the bucket with clean water and add a little mold detergent.
- Move the solution around in the water tank. Empty the water tank, rinse, and dry.

Troubleshooting

The unit does not start operation.	<ul style="list-style-type: none">□ The water tank may be full with water. Remove the tank and drain the water.□ The power supply cord may not be connected properly. Connect the power supply cord properly into a grounded wall outlet.□ The water tank is not securely placed into its correct position. The unit will not operate unless the water tank is inserted securely.□ The house fuse may be blown or the circuit breaker may have tripped. Contact a qualified service technician and replace the fuse with a time delay type or reset the circuit breaker.□ The unit may have been turned on/off too quickly. Turn the unit off and wait 3 minutes before restarting.
The unit does not dry the air as it should.	<ul style="list-style-type: none">□ The air flow may be restricted. Verify that nothing is blocking the air inlet and outlet.□ The doors and windows may be open. Close all the doors and windows.□ The room temperature may be too low. Increase the room temperature using another heat source if necessary.□ The area surrounding the unit may be too large. Use the unit in a smaller area.
The red LED light stays on.	<ul style="list-style-type: none">□ The water tank may not be secured into its proper position. Reinstall the tank into its correct position.
Noise when the unit is in operation.	<ul style="list-style-type: none">□ The surface may not be level or flat. Place the unit on a flat or level surface.



Contact info.

Phone: 1300 030 367

email: info@vitality.com.au